

DUR-A-GARD SL

IMPORTANT! Read these instructions carefully several days prior to starting your work. Seek answers to any questions you may have before you begin. DUR-A-FLEX, Inc. maintains a Technical Staff that will be glad to answer your questions and give you advice pertaining to your particular installation. DUR-A-FLEX Power Mixers are highly recommended for mixing cove base and patching compound. Material for small areas can be mixed with a 1/2" - 3/4" heavy duty, slow speed, electric drill equipped with a DUR-A-FLEX bird-cage mixing attachment and a 5 gallon metal pail.

SURFACE PREPARATION

Surface must be sound, dry and perfectly clean, free of all oil, grease, detergent film, sealers and/or curing compounds. A surface profile of 10 to 15 mils is appropriate for most applications. All paint should be removed unless it is a properly applied, totally de-glossed, high quality epoxy. Upper level rooms, like mechanical rooms, bathrooms, or wet process areas that have space below should receive ELAST-O-COAT seamless fluid applied membrane. Please refer to the DUR-A-FLEX Surface Preparation Guide on our website for detailed instructions. No epoxy coatings should be applied unless surface temperature is a minimum of 5 degrees F above dew point. See Dew Point Calculation Chart on our website for detailed instructions.

MIXING AREA

Select a convenient mix area and protect the surface from spillage by covering with a layer of cardboard and/or sheet of plastic. Be generous with the amount of space you allocate for this function. The more comfortably your mixer works, the less likely you are to have a "mix error". Make ready all necessary tools, mix and measure containers, etc. **DO NOT MIX ANY EPOXY UNTIL READY FOR IMMEDIATE USE.** Once hardener and resin are combined, it must be used without delay. Working time is dependent on choice of hardener, size of batch, time to place on floor and temperature of floor and product. Apply masking tape to wherever coating is intended to stop. To obtain neat, straight, chip resistant edges at termination points and/or drains, a "keyed edge" must be installed.

PRIMING

All surfaces must be primed with DUR-A-SHIELD, DUR-A-GLAZE WB, DUR-A-GLAZE #4 TIE-COAT II or DUR-A-GLAZE #4 100% Solids Epoxy as soon as the surface has been prepared.

QUALITY CONTROL

The color of DUR-A-GARD resin may vary slightly from batch to batch. It is recommended that the lot number on the side of the resin pail be checked. If lot numbers are different, box together the different lot numbers to ensure a uniform color for topcoat applications.

1. APPLICATION METHOD

- A. Prime surface with appropriate primer and spread rate.
- B. Pre-mix DUR-A-GLAZE Hardener (Water Clear or Regular) and SHOP FLOOR Resin thoroughly before mixing together.
- C. Measure out 1/2 gallon DUR-A-GLAZE Hardener and 1 gallon SHOP FLOOR Resin. When combining, be sure to add the hardener first. Add the resin and scrape out the container. Be careful to pour both hardener and resin into the center of the mixing pail. Mix the blended epoxy with a slow speed power drill with a Jiffler mixing blade for 2-3 minutes. Always scrape the sides and bottom of the mixing bucket to assure thorough blending.
- D. **Always scrape the sides and bottom of the mixing bucket to assure thorough blending.**
- E. Apply aggregates and fillers and SHOP FLOOR liquids to a primed substrate with a 1/4", 3/8" or 1/2" notched squeegee, depending on thickness desired. **See chart below for mix ratio and squeegee size.**
Gently back roll with a loop roller to ensure even distribution of blended aggregates and fillers.
Cross roll entire area and allow to cure.
- F. See *TOPCOAT INSTRUCTIONS*.

Self-Level Systems (Epoxy)

35 mil Dur-A-Gard SL: 1 mix covers 100 sq. ft., 1 ½ gal. Shop Floor, 3 quarts 290 Flour & 3 quarts F-60 sand.

(Use ¼” squeegee a 35 mil system)

60 mil Dur-A-Gard SL: 1 mix covers 70 sq. ft., 1 ½ gal. Shop Floor, 3 quarts. 290 Flour & 3 quarts F-60 sand.

(Use 3/8” squeegee for a 60 mil system)

100 mil Dur-A-Gard SL: 1 mix covers 45 sq. ft., 1 ½ gal. Shop Floor, 4 quarts. 290 Flour & 4 quarts F-60 sand.

(Use ½” squeegee for a 100 mil system)

2. TOPCOAT INSTRUCTIONS

Select appropriate Topcoat and follow its application instructions. (Apply Armor Top per Product Data Sheet instructions).

For an orange peel finish, apply a coat of DUR-A-GARD OPF at a coverage rate of 350 – 500 Sq Ft per gallon. For an aggressive orange peel texture, apply a coat of CRETE-GARD at a coverage rate of 100 – 200 Sq Ft per gallon.

JOINT GUIDELINES

Refer to the Joint Guidelines for complete details on our website.

IMPORTANT: Increasing room temperature to accelerate cure is not recommended, a slight reduction (3°-5°F) from reasonable room temperature may help reduce outgassing. **DUR-A-GARD is a high gloss finish; special care should be given to avoid surface contamination. USE SIGNS AND BARRIERS** to keep traffic out of the area. Do not allow any water on coated surface for 24-48 hours. **NOTE:** Use DUR-A-SOLVE or Xylene for clean up.

THICKNESS OF COATING APPLIED (1000 MILS = 1 INCH)		COVERAGE PER US GALLON 100% SOLIDS SYSTEM	
	20 MILS	80.0	SQ FT/GAL
1/64 IN. =	16 MILS	102.0	SQ FT/GAL
	10 MILS	160.0	SQ FT/GAL
	8 MILS	200.0	SQ FT/GAL

CAUTION

Follow the Hazardous Materials Identification System labeling guide for proper personal protective equipment to use when handling this product. Use only as directed. KEEP OUT OF REACH OF CHILDREN.

Before using any DUR-A-FLEX, Inc. product, be sure the Material Safety Data Sheet is read and understood.