


BOUNDARY DESCRIPTIONS

BEGINNING AT THE NORTH QUARTER CORNER OF SECTION 11, TOWNSHIP 43 SOUTH, RANGE 15 WEST, SALT LAKE BASE AND MERIDIAN; AND RUNNING THENCE SOUTH 89°07'43" EAST 164.82 FEET ALONG THE NORTH LINE OF SAID SECTION 11; THENCE SOUTH 89°07'43" EAST 164.82 FEET ALONG THE NORTH LINE OF SAID SECTION 11; THENCE NORTH 0°07'43" EAST 164.82 FEET ALONG SAID LINE TO THE POINT OF BEGINNING.



ZONE CHANGE EXHIBIT

NORTHEAST 1/4 OF SECTION 11, TOWNSHIP 43 SOUTH, RANGE 15 WEST, SALT LAKE BASE AND MERIDIAN